

Procédure pour configuration douchette MK9520-37A38

Codes barres à scanner.

1. Page 1-1 : Enter / Exit

Enter/Exit Configuration Mode



2. Page 11-2 : Belgium Keyboard



Belgium Keyboard

3. Page 11-5 : Enable CAPS Lock



Enable Caps Lock (XT)

4. Page 15-1 : Enable USB interface



Enable USB Interface

5. Page 1-1 : Enter / Exit

Enter/Exit Configuration Mode

